
Visual Verification Bridge Powered by CHEKT.

CKB-304v2 Wiring Guide








Note: The Bridge draws 400mA peak. When powering the Bridge from the alarm panel, consider this when estimating your powered devices and back up battery.

In most cases*, an additional power supply is recommended. If a separate power supplyis used, the ground must remain common between the power supply, alarm panel & Bridge.




Note: This will allow you to arm/disarm the Bridge with the alarm panel.





CKB-304v2 Visual Verification Bridge

O DO NOT REMOVE




EXAMPLE


This is a typical burg zone with the EOL at the device.







share a common ground with the alarm panel. Otherwise, the Zone Ground must be wired to the Bridge Input Ground.





ALARM PANEL PROGRAMMING:

PGM 1 To Arm/Disarm

[009][001]: 05 (End Of Exit Delay)

[551]: Select Correct Partition

CHeKT DEALER PORTAL: Bridge Programming

We recommend using "High Voltage Arming" when possible. This defaults to the Bridge being in an armed state if the wiring for the Arming Pin gets compromised or disconnected for any reason.